



EXPLC communication construction – Modbus Rtu mode with EX485LNK


◆ Configuration



Terminal connection:



Switches of EXRM0808 :



Note : About communication format of 485LNK, please refer to user's manual of EX485LNK; format of Remote I/O, refer to manual of EXRM0808

◆ Program action

X12 ON : communication is started

Transmission of this example as follows,

Data of master D2000 are sent to D4 of slave 1

Master D1000 receives data from D0 of slave 1

Data of master D2020 are sent to D4 of slave 2

Master D1020 receives data from D0 of slave 2

Data of master D2040 are sent to D4 of slave 3

Master D1040 receives data from D0 of slave 3

◆ Program function